

Please replace the paragraph beginning at page 13, line 9 with the following:

A2 If FullLoadCondenserApproach is less than OptimalCondenserApproach, there is no efficiency loss. If FullLoadCondenserApproach exceeds OptimalCondenserApproach, then the ApproachDifference between them is computed:

Please delete the paragraph beginning at page 13, line 16.

Please delete Equation 5 on page 13.

Please replace the paragraph beginning on page 13, line 24 with the following:

A3 There is believed to be an efficiency loss of approximately two percent for every unit of ApproachDifference:

Please replace Equation 6 on page 13 with the following:

A4 (5)  $\text{CondenserApproachLoss} = \text{ApproachDifference} * 2\%$

Please replace Equation 7 on page 15 with the following:

A5 (6)  $\text{NonCondensables} = P_{\text{COND}} - \text{OptimalCondenserPressure}$

Please replace Equation 8 on page 15 with the following:

A6 (7)  $\text{NonCondLoss} = \text{NonCondensables} * \text{MultiplierConstant}$

Please replace Equation 9 on page 16 with the following:

A7 (8)  $\text{CondenserActualDeltaP} = P_{\text{COND\_IN}} - P_{\text{COND\_OUT}}$

Please replace Equation 10 on page 16 with the following:

A8 (9)  $\text{DeltaVariance} = \text{square root of } (\text{CondenserActualDeltaP} / \text{CondenserOptimalDeltaP})$

Please replace Equation 11 on page 17 with the following:

A9 (10)  $\text{FinalVariance} = (1 - \text{DeltaVariance}) * (T_{\text{COND\_OUT}} - T_{\text{COND\_IN}})$

Please replace Equation 12 on page 17 with the following:

A10 (11)  $\text{FlowLoss} = \text{FinalVariance} * 2\%$

Please replace Equation 13 on page 18 with the following:

A11 (12)  $\text{Flow} = (1 - \text{DeltaVariance}) * 100$

Please replace Equation 14 on page 19 with the following:

A12 (13)  $\text{FullLoadEvaporatorApproach} = (T_{\text{EVAP\_OUT}} - \text{UseTemp}) * (\text{FullLoadCurrent} / \text{RunningCurrent})$

Please replace Equation 15 on page 19 with the following:

A13 (14)  $\text{EvaporatorApproachLoss} = 2\% * (\text{FullLoadEvaporatorApproach} - \text{OptimalEvaporatorApproach})$